




10. SCHEMATIC DIAGRAM OF AUDIO SECTION



* Design and specifications subject to change without notice for improvements.



9. SCHEMATIC DIAGRAM OF TUNER SECTION



- SELECTOR S701(a-o)
1. PHONO 2
 2. PHONO 1
 3. FM AUTO
 4. AM
 5. AUX
- FUNCTION S702(a-l)
1. 2-CH
 2. QS SYNTHESIZER
 3. QS REGULAR MATR
 4. PHASE MATRIX
 5. DISCRETE/CD-4
- TAPE MONITOR 2-CH S
1. OFF
 2. ON

